X-431 MAZDA DIAGNOSTIC FUNCTION LIST (V14.00)

YEAR	MODEL	SYSTEM	PROTOCOL	READ DTC	CLEAR DTC	DATA STREAM	READ ECU ID	ACTUATION TEST
2002～2004	01.MAZDA 6	ENG	CAN BUS	√	√	√		
		AT	CAN BUS	√	√	√		
		ABS	FORD KWP 2000	√	√	√		
		SRS	FORD KWP 2000	√	√	√		
		IC	CAN BUS	√	√	√		
	02.GENERAL MAZDA	ENG	flash code	√	√			
		AT	flash code	√	√			
		ABS	flash code	√	√			
		SC	flash code	√	√			
	03.MAZDA PREMACY	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
	01. 01 GY AT MPV(CALIF.)	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	02. 01 GY A T MPV(FED,CANADA)	PCM	PCM_CLASS	√	√	√		
		ABS	ABS_CLASS	√	√	√		
		CCM	Flash code	√	√			
	03. 01 ZM MT PROTEG	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	04. 01 ZM AT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	05. 01 FP MT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	06. 01 FP AT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	07. 01 FS MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	08. 01 FS AT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	09. 01 KL MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	10. 01 KL AT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	11. 01 BP MT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	12 . 01 BP AT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	13. 01 KL AT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
		A/C	flash code	√	√			
	14. 01 KJ AT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
		A/C	flash code	√	√			
	15. 01 YF MT TRIBUTE(EP)	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		ICM	ICM_pwm	√	√	√		
		RCM	RCM_CLASS	√	√	√	√	√
	16. 01 YF AT TRIBUTE(EP)	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		ICM	ICM_pwm	√	√	√		
		RCM	RCM_CLASS	√	√	√	√	√
	17. 01 AJ AT TRIBUTE(EP)	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		ICM	ICM_pwm	√	√	√		
		RCM	RCM_CLASS	√	√	√	√	√
	18 . 01 2.3L AT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
		-4X4	-4X4_CLASS	√	√	√	√	√
	19. 01 2.3L MT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
		-4X4	-4X4_CLASS	√	√	√	√	√
	20. 01 2.5L AT B2500	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
		-4X4	-4X4_CLASS	√	√	√	√	√
		PCM	PCM_pwm	√	√	√		

21. 01 2.5L MT B2500	ABS	ABS_CLASS	√	√	√		√
	GEM	GEM_CLASS	√	√	√	√	√
	IABM	IABM_CLASS	√	√	√	√	√
	RAP	RAP_CLASS	√	√	√	√	√
	-4X4	4X4_CLASS	√	√	√	√	√
22. 01 3.0L AT B3000	PCM	PCM_pwm	√	√	√		
	ABS	ABS_CLASS	√	√	√		√
	GEM	GEM_CLASS	√	√	√	√	√
	IABM	IABM_CLASS	√	√	√	√	√
	RAP	RAP_CLASS	√	√	√	√	√
	-4X4	4X4_CLASS	√	√	√	√	√
23. 01 3.0L MT B3000	PCM	PCM_pwm	√	√	√		
	ABS	ABS_CLASS	√	√	√		√
	GEM	GEM_CLASS	√	√	√	√	√
	IABM	IABM_CLASS	√	√	√	√	√
	RAP	RAP_CLASS	√	√	√	√	√
	-4X4	4X4_CLASS	√	√	√	√	√
24. 01 4.0L AT B4000	PCM	PCM_pwm	√	√	√		
	ABS	ABS_CLASS	√	√	√		√
	GEM	GEM_CLASS	√	√	√	√	√
	IABM	IABM_CLASS	√	√	√	√	√
	RAP	RAP_CLASS	√	√	√	√	√
	-4X4	4X4_CLASS	√	√	√	√	√
25. 01 4.0L MT B4000	PCM	PCM_pwm	√	√	√		
	ABS	ABS_CLASS	√	√	√		√
	GEM	GEM_CLASS	√	√	√	√	√
	IABM	IABM_CLASS	√	√	√	√	√
	RAP	RAP_CLASS	√	√	√	√	√
	-4X4	4X4_CLASS	√	√	√	√	√
121 (DB) B3(MT/AT)	PCM	flash code	√	√			
	TCM	flash code	√	√			
121 (DB) B5(MT/AT)	PCM	flash code	√	√			
	TCM	flash code	√	√			
121 (DB) B5(MT/AT) DB1053	PCM	flash code	√	√			
121/121 DEMIO(DW) B3(MT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
121/121 DEMIO(DW) B3(AT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
121/121 DEMIO(DW) B5(MT)	PCM	PCM_CLASS	√	√	√		√
121/121 DEMIO(DW) B5(AT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
121/121 DEMIO(DW) B3(MT) DW1052	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
121/121 DEMIO(DW) B3(AT) DW1052	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
121/121 DEMIO(DW) B3(MT) DW1032#203028	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
121/121 DEMIO(DW) B3(AT) DW1032#203028	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
121/121 DEMIO(DW) B5(MT) DW1052	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
121/121 DEMIO(DW) B5(AT) DW1052	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
121/121 DEMIO(DW) B5(MT) DW1032#203028	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
121/121 DEMIO(DW) B5(AT) DW1032#203028	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS	√	√	√	√	√
323 (BG) B3(MT/AT)	PCM	flash code	√	√			
	ABS	flash code	√	√			
	TCM	flash code	√	√			
323 (BG) B6(MT/AT)	PCM	flash code	√	√			
	ABS	flash code	√	√			
	TCM	flash code	√	√			
323 (BG) BP(MT/AT)	PCM	flash code	√	√			
	ABS	flash code	√	√			
	TCM	flash code	√	√			
323 (BG) ADR BP-SOHC(AT) BG10P2	PCM	flash code	√	√			
	ABS	flash code	√	√			
323 (BA) B3(MT)	PCM	PCM_CLASS/flash code	√	√	√		√
	ABS	flash code	√	√			
323 (BJ) B3(MT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
323 (BJ) ZL(MT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
323 (BJ) ZL(AT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
323 (BJ) ZM(MT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
323 (BJ) ZM(AT)	PCM	PCM_CLASS	√	√	√		√
	ABS	ABS_CLASS/flash code	√	√	√	√	√
	PCM	PCM_CLASS	√	√	√		√

	323 (BJ) FP(MT)	ABS	ABS_CLASS/flash code	√	√	√	√	√
	323 (BJ) FP(AT)	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS/flash code	√	√	√	√	√
	323 (BJ) RF-I(MT)	PCM	PCM_CLASS	√	√	√		√
	323 (BJ) B3(MT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	323 (BJ) ZL(MT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	323 (BJ) ZL(AT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	323 (BJ) ZM(MT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	323 (BJ) ZM(AT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	323 (BJ) FP(MT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	323 (BJ) FP(AT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	MX-5 (NB) BP(MT)	PCM	PCM_CLASS	√	√	√		√
	MX-5 (NB) BP(AT)	PCM	PCM_CLASS	√	√	√		√
	MX-5 (NB) BP(MT) NB30P2	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	MPV(LW) FS(AT)	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	MPV(LW) GY(AT)	PCM	PCM_CLASS	√	√	√		√
	B-SERIES(UF) G6(MT)	PCM	PCM_CLASS	√	√	√		√
	B-SERIES(UF) G6(AT)	PCM	PCM_CLASS	√	√	√		√
	B-SERIES(UF) F2(MT)	PCM	PCM_CLASS	√	√	√		√
	B-SERIES(UN) G6(MT)	PCM	PCM_CLASS	√	√	√		√
	B-SERIES(UN) G6(MT)	PCM	PCM_CLASS	√	√	√		√
	B-SERIES(UN) F2(MT)	PCM	PCM_CLASS	√	√	√		√
	E-SERIES (SR) FE-EGI(MT)	PCM	PCM_CLASS	√	√	√		√
	E-SERIES(SK,SL) F8-EGI(MT)	PCM	PCM_CLASS	√	√	√		√
	E-SERIES(SK,SL) FE-EGI(MT)	PCM	PCM_CLASS	√	√	√		√
	BONGO FRIENDEE(SG) J5(AT)	PCM	PCM_CLASS	√	√	√		√
	BONGO FRIENDEE(SG) J5(AT) SG10J4	PCM	PCM_CLASS	√	√	√		√
		A/C	flash code	√	√			
		ABS	flash code	√	√			
		TCM	TCM_CLASS	√	√	√		√
	PREMACY (CP) FP(AT)	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
	626 (GF) FS(MT)	PCM	PCM_PWM	√	√	√		
	626 (GF) FS(AT)	PCM	PCM_PWM	√	√	√		
	626 (GF) FS(MT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√	√	√
	626 (GF) FS(AT) #200001	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
	626 WAGON(GW) FS(MT)	PCM	PCM_PWM	√	√	√		
	626 WAGON(GW) FS(AT)	PCM	PCM_PWM	√	√	√		
	626 WAGON(GW) FS(MT) #200001	PCM	PCM_PWM	√	√	√		
	626 WAGON(GW) FS(MT) #200001	PCM	PCM_PWM	√	√	√		
	1. 00 GY AT MPV(CALIF.)	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS _CLASS	√	√	√		√
		CCM	flash code	√	√			
	2. 00 GY AT MPV(FED,CANADA)	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	3 00 ZM MT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	4 00 ZM AT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	5 00 FP MT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	6 00 FP AT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	7 00 FS MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	8 00 FS AT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	9 00 KL MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	10 00 KL AT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	11 00 BP MT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	flash code	√	√			
		CCM	flash code	√	√			
	12 00 BP AT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	flash code	√	√			
		CCM	flash code	√	√			
	13 00 KL AT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	flash code	√	√			
		ABS	ABS_CLASS	√	√	√		√

		CCM	flash code	√	√			
02. 2000-VIN#10:Y	14 00 KJ AT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	flash code	√	√			
		ABS	ABS_CLASS	√	√	√		√
		CCM	flash code	√	√			
	15 00 2.5L AT B2500	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
	16 00 2.5L MT B2500	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
	17 00 3.0L AT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
	18 00 3.0L MT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
		PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
	20 00 4.0 L MT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
03. 1999-VIN#10:X	1 99 ZM MT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	2 99 ZM AT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	3 99 FP MT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	4 99 FP AT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	5 99 FS MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√			
	6 99 FS AT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	7 99 KL MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	8 99 KL AT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	9 99 BP MT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	10 99 BP AT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	11 99 JE AT MPV	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	12 99 KL AT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	13 99 KJ AT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	14 99 KL AT MILLENIA(NEW ABS)	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	ABS_CLASS	√	√	√		√
		CCM	Flashcode	√	√			
	15 99 KJ AT MILLENIA(NEW ABS)	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	ABS_CLASS	√	√	√		√
		CCM	Flashcode	√	√			
		PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√

	16 99 2.5L AT B2500	GEM	GEM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
		RCM	RCM_CLASS	√	√	√	√	√
	17 99 2.5L MT B2500	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
		RCM	RCM_CLASS	√	√	√	√	√
	18 99 3.0L AT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
		RCM	RCM_CLASS	√	√	√	√	√
	19 99 3.0L MT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
		RCM	PCM_CLASS	√	√	√	√	√
	2099 4.0L AT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
		RCM	RCM_CLASS	√	√	√	√	√
	21 99 4.0L MT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		PATS	PATS_pwm CLASS	√	√	√		
		RAP	RAP_CLASS	√	√	√	√	√
		RCM	RCM_CLASS	√	√	√	√	√
04. 1998-VIN#10:W	1 98 Z5 MT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	2 98 Z5 ECAT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	3 98 BP MT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	4 98 BP ECAT PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	5 98 FS MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	6 98 FS ECAT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	7 98 KL MT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	8 98 KL ECAT 626	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
	9 98 JE ECAT MPV	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	10 98 KL ECAT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	11 98 KJ ECAT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	12 98 2.5L AT B2500	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	13 98 2.5L MT B2500	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	14 98 3.0L AT B3000	PCM	PCM_pw	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	15 98 3.0L MT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	16 98 4.0L AT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√

	17 98 4.0L MT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	1 97 Z5 MT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	2 97 Z5 ECAT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	3 97 BP MT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	4 97 BP ECAT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	5 97 FS MT 626/MX-6	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	6 97 FS ECAT 626/MX-6	PCM	PCM_pwm	√	√	√		
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	.7 97 KL MT 626/MX-6	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	8 97 KL ECAT 626/MX-6	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	9 97 BP MT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	10 97 BP ECAT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	11 97 JE ECAT MPV	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	12 97 KL ECAT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
05. 1997-VIN#10:V	13 97 KJ ECAT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	14 97 2.3L AT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√			
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	15 97 2.3L MT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	16 97 3.0L AT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	17 97 3.0L MT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	18 97 4.0L AT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	19 97 4.0L AT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	1 96 Z5 MT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	2 96 Z5 ECAT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	3 96 BP MT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	4 96 BP ECAT 323/PROTEGE	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	5 96 FS MT 626/MX-6	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
		PCM	PCM_pwm	√	√	√		

06. 1996-VIN#10:T	6 96 FS ECAT 626/MX-6	ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	7 96 KL MT 626/MX-6	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	8 96 KL ECAT 626/MX-6	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	9 96 ECAT 929	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	10 96 BP MT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	11 96 BP ECAT MIATA	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	12 96 B6 MT MX-3	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	13 96 B6 ECAT MX-3	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	14 96 K8 MT MX-3	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	15 96 K8 ECAT MX-3	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
	16 96 JE ECAT MPV	PCM	PCM_CLASS	√	√	√		√
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	17 96 KL ECAT MILLENIA	P CM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	18 96 KJ ECAT MILLENIA	PCM	PCM_CLASS	√	√	√		√
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	19 96 2.3L AT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	20 96 2.3L MT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	21 96 3.0L AT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	22 96 3.0L MT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	23 96 4.0L AT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	24 96 4.0L MT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		√
		GEM	GEM_CLASS	√	√	√	√	√
		IABM	IABM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	1 95 Z5 MT 323/PROTEGE	PCM	PCM_pwm_95_323	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	2 95 Z5 ECAT 323/PROTEGE	PCM	PCM_pwm_95_323	√	√			
		ABS	flashcode	√	√			
		CCM	flashcode	√	√			
	3 95 BP MT 323/PROTEGE	PCM	PCM_pwm_95_323	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	4 95 BP ECAT 323/PROTEGE	PCM	PCM_pwm_95_323	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	5 95 FS MT 626/MX-6	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	6 95 FS ECAT 626/MX-6	PCM	Ford flash code	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	7 95 KL 626/MX-6	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
		PCM	Flashcode	√	√			

06. 1995-VIN#10:T	8 95 ALL 929	A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	9 95 B6 MX-3	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		TCM	Flashcode	√	√			
	10 95 K8 MX-3	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		T CM	Flashcode	√	√			
	11 95 ALL MIATA	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		TCM	Flashcode	√	√			
	12 95 ALL RX-7	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	13 95 G6 MPV	PCM	Flashcode	√	√			
	14 95 JE MPV	PCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	15 95 KL MILLENIA	PCM	PCM_pwm_95_323	√	√			
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	16 95 KJ MILLENIA	PCM	PCM_pwm_95_323	√	√			
		A/C	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	17 95 2.3L AT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√		
		GEM	GEM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	18 95 2.3L MT B2300	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√	√	√
		GEM	GEM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	19 95 3.0L AT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√	√	√
		GEM	GEM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	20 95 3.0L MT B3000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√	√	√
		GEM	GEM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	21 95 4.0L AT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√	√	√
		GEM	GEM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
	22 95 4.0L MT B4000	PCM	PCM_pwm	√	√	√		
		ABS	ABS_CLASS	√	√	√	√	√
		GEM	GEM_CLASS	√	√	√	√	√
		RAP	RAP_CLASS	√	√	√	√	√
08: 1994-VIN#10:R	1 94 ALL 323/PROTEGE	PCM	Flascode	√	√			
		TCM	Flashcode	√	√			
	2 94 FS MT 626/MX-6	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
	3 94 FS ECAT 626/MX-6	PCM	Ford flash code	√	√			
		ABS	Flashcode	√	√			
		C CM	Flashcode	√	√			
	4 94 KL 626/MX-6	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		CCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	5 94 ALL 929	PCM	flashcode	√	√			
		A/C	flashcode	√	√			
		CCM	flashcode	√	√			
		TCM	Flashcode	√	√			
	6 94 B6 MX-3	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		TCM	Flashcode	√	√			
	7 94 K8 MX-3	PCM	Flashcode	√	√			
		ABS	Flashcode	√	√			
		TCM	Flashcode	√	√			
	8 94 ALL MIATA	PCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	9 94 ALL RX-7	PCM	Flashcode	√	√			
		CCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	10 94 G6 MPV	PCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	11 94 JE MPV	PCM	Flashcode	√	√			
		TCM	Flashcode	√	√			
	12 94 4.0L NAVAJO	PCM	Ford flash code	√	√			
		ABS	Flashcode	√	√			
	13 94 2.3L 49S B2300	PCM	Ford flash code	√	√			
	14 94 2.3L CAL B2300	PCM	Ford flash code	√	√			
	15 94 3.0L B3000	PCM	Ford flash code	√	√			

	16 94 4.0L 49S B4000	PCM	Ford flash code	√	√			
	17 94 4.0L CAL B4000	PCM	Ford flash code	√	√			
09: 1993-VIN#10:P	93 ALL VEHICLES EXCEPT NAVAJO	PC M	flash code	√	√			
		A/C	flash code	√	√			
		ABS	flash code	√	√			
		CCM	flash code	√	√			
		TCM	flash code	√	√			
	93 4.0L 49S NAVAJO	PCM	Ford flash code	√	√			
		ABS	flash code	√	√			
	93 4.0L CAL NAVAJO	PCM	Ford flash code	√	√			
		ABS	flash code	√	√			
10: 1992-VIN#10:N	92 ALL VEHICLES EXCEPT NAVAJO	PCM	flash code	√	√			
		A/C	flash code	√	√			
		ABS	flash code	√	√			
		CCM	flash code	√	√			
		TCM	flash code	√	√			
	92 4.0L NAVAJO	PCM	Ford flash code	√	√			
11: 1991-VIN#10:M	91 ALL VEHICLES EXCEPT NAVAJO	PCM	flash code	√	√			
		TCM	flash code	√	√			
	91 4.0L NAVAJO	PCM	Ford flash code	√	√			
12: 1990-VIN#10:L	90 ALL VEHICLES	PCM	flash code	√	√			
		TCM	flash code	√	√			
13: 1989-VIN#10:K	89 ALL VEHICLES	PCM	flash code	√	√			
		TCM	flash code	√	√			
14: 1988-VIN#10:J	88 ALL VEHICLES	PCM	flash code	√	√			
		TCM	fl ash code	√	√			