

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

MODEL	SYSTEM	SUB SYSTEM	FUNCTION			
01. ATOS F_LIFT 04 ALL	01. ENGINE SYSTEM	01. UNLEAD GEN	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		02. UNLEAD EOBD	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		03. UNLEAD MEX	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		04. LEAD ALL	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
	02. AUTOMATIC TRANSAXLE SYSTEM		1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
	03. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION 4 AIR BLEED
	04. SRS-AIRBAG		1	READ/CLEAR DTC	2 DATA STREAM	
02. ATOS 1998-2004	01. ENGINE L4-SOHC	01. UNLEAD GENERAL	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		02. UNLEAD EOBD	1	READ/CLEAR DTC	2 DATA STREAM	
		03. UNLEAD MEX	1	READ/CLEAR DTC	2 DATA STREAM	
		04. UNLEAD IMM	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		05. LEAD ALL	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		06. UNLEAD GENERAL SANTRO	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		07. LEAD GENERAL SANTRO	1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
	02. AUTOMATIC TRANSAXLE SYSTEM		1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
	03. SAT SYSTEM					
	04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION 4 AIR BLEED
05. AIRBAG SYSTEM		1	READ/CLEAR DTC	2 DATA STREAM		
03. GETZ 2003-2004	01. ENGINE (GASOLINE)	01. UNLEAD GEN	1	READ/CLEAR DTC	2 DATA STREAM	
		02. LEAD ALL	1	READ/CLEAR DTC	2 DATA STREAM	
		03. UNLEAD EOBD	1	READ/CLEAR DTC	2 DATA STREAM	
	02. ENGINE-DIESEL		1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
	03. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
	04. SRS AIRBAG		1	READ/CLEAR DTC	2 DATA STREAM	
05. IMMOBILIZER	01. GASOLINE	1	DATA STREAM			
	02. DIESEL	1	DATA STREAM			
04. ACCENT 2003-2004	01. ENGINE (GASOLINE)	01. UNLEAD GEN	1	READ/CLEAR DTC	2 DATA STREAM	
		02. LEAD ALL	1	READ/CLEAR DTC	2 DATA STREAM	
		03. UNLEAD EOBD	1	READ/CLEAR DTC	2 DATA STREAM	

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		04. UNLEAD 03MY OBD-11	1 READ/CLEAR DTC 2 DATA STREAM		
		05. UNLEAD 04MY OBD-11	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION		
		02. ENGINE-DIESEL	01 . GENERAL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION	
			02 . EOBD	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION	
		03. AUTOMATIC TRANSAXLE	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION		
		04. ANTI -LOCK BRAKE SYSTEM	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION 4 AIR BLEED		
		05. SRS-AIRBAG	01. SRE-LC/HMC	1 READ/CLEAR DTC 2 DATA STREAM	
			02. SRE-SMART(DUAL. STAGE)	1 READ/CLEAR DTC 2 DATA STREAM	
		06. IMMOBILIZER	01. GASOLINE	1 DATA STREAM	
			02. DIESEL	1 DATA STREAM	
		04. ACCENT 2000-2002	01. ENGINE L4-SOHC	01. LEAD ALL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
				02. UNLEAD(GENERAL) ALL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
03. UNLEAD(EOBD) ALL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION				
04. UNLEAD(OBD-11) ALL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION				
05. UNLEAD(GENERAL India)	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION				
02. ENGINE L4-DOHC	01. LEAD ALL		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION		
	02. UNLEAD(GENERAL) ALL		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION		
	03. UNLEAD(EOBD) ALL		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION		
	04. UNLEAD(OBD-11) ALL		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION		
	05. UNLEAD(GENERAL India)		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION		
03. ENGINE-DIESEL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION				
04. AUTOMATIC TRANSAXLE	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION				
05. ANTI -LOCK BRAKE SYSTEM	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION 4 AIR BLEED				
06. SRS-AIRBAG	1 READ/CLEAR DTC 2 DATA STREAM				
07. IMMOBILIZER	01. GASOLINE		1 READ/CLEAR DTC		
	02. DIESEL		1 DATA STREAM		
04. ACCENT 1995-1999	01. ENGINE L4-SOHC		01. UNLEAD 1.3L 95-97MY GEN	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION	
			02. UNLEAD 1.3L 95-97MY IMM	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION	
			03. UNLEAD 1.3L 98MY GEN	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION	

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		04. UNLEAD 1.3L 98MY IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		05. UNLEAD 1.5L 95MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		06. UNLEAD 1.5L 95MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		07. UNLEAD 1.5L IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		08. UNLEAD 1.5L 95-97MY KOR	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		09. UNLEAD 1.5L 98MY KOR	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		10. LEAD 1.5L 95MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		11. LEAD 1.5L 96-99MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		12. UNLEAD 96-97MY OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		13. UNLEAD 98-99MY OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. ENGINE L4-DOHC	01. UNLEAD 1.5L 95-97MY MAF	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. UNLEAD 1.5L 97MY IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			03. UNLEAD 1.5L 98-99MY IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	04. UNLEAD 1.5L 97-98MY MAP		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	05. UNLEAD 96-97MY OBD-II		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	06. 1.5L DOHC MAF		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	07. 1.5L DOHC MAP		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	08. 1.5L DOHC L/B		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	09. 1.3L SOHC ..97		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	10. 1.3L SOHC 98		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	11. 1.5L SOHC ..97		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	12. 1.5L SOHC 98		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	03. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM				
05. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM				
05. EXCEL 1990-1994	01. ENGINE L4-SOHC	01. 90-94MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. 1.5L SOHC	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. 1.5L SIEMENS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	02. AUTOMATIC TRANSAXLE SYSTEM	01. 90-94MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		02. 1.5L SOHC	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. 1.5L SIEMENS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
06. SCOUPE	1991-1996	01. UNLEAD 94-96MY GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. UNLEAD 92-94MY ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. UNLEAD 91-92MY ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		04. UNLEAD 94-96MY FED	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		05. UNLEAD 94-96MY CAL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		06. LEAD 93-96MY ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		07. SCOUPE LS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		08. SCOUPE 91-92MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		09. SCOUPE 93-94MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		10. SCOUPE 95MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		11. SCOUPE RURBO 92-94MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		12. SCOUPE RURBO 95MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	02. ENGINE L4-DOHC TRUBO	01. UNLEAD 94-96MY ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. UNLEAD 92-94MY ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. UNLEAD 92MY KOR	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
03. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION			
07. MATRIX	2002-2004	01. ENGINE (GASOLINE)	01. LEAD 1.6L ALL	1	READ/CLEAR DTC	2	DATA STREAM			
			02. UNLEAD 1.6L GEN	1	READ/CLEAR DTC	2	DATA STREAM			
			03. UNLEAD 1.6L EOBD	1	READ/CLEAR DTC	2	DATA STREAM			
			04. LEAD 1.8L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			05. UNLEAD 1.8L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			06. UNLEAD 1.8L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	02. ENGINE (DIESEL)	01. GENERAL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	03. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
	05. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM				

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

08. ELANTRA	2004-2005	01. ENGINE (GASOLINE)	01. LEAD 1.6L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. UNLEAD 1.6L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			03. UNLEAD 1.6L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			04. LEAD 1.8/2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			05. UNLEAD 1.8/2.0L (-CVVT) GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			06. UNLEAD 1.8/2.0L (+CVVT) GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			07. UNLEAD 1.8/2.0L (CVVT) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			08. UNLEAD 2.0L (CVVT) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	02. ENGINE (DIESEL)		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	03. AUTOMATIC TRANSAXLE	01. 1.6L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. 1.8/2.0L (SIEMENS PCM)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED	
	05. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM			
08. ELANTRA	2001-2003	01. ENGINE (GASOLINE)	01. LEAD 1.6L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. UNLEAD 1.6L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			03. UNLEAD 1.6L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			04. LEAD 1.8/2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			05. UNLEAD 1.8/2.0L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			06. UNLEAD 1.8/2.0L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			07. UNLEAD 2.0L (-SULEV) OBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			08. UNLEAD 2.0L (SULEV) OBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	02. ENGINE (DIESEL)		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	03. AUTOMATIC TRANSAXLE	01. 1.6L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. 1.8/2.0L (MELCO TCM)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. 1.8/2.0L (SIEMENS PCM)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED	
05. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM				
08. ELANTRA	1996-2000	01. ENGINE L4-SOHC	01. UNLEAD 1.5L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. UNLEAD 1.5L IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

	02. ENGINE L4-DOHC	03. LEAD 1.5L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		01. UNLEAD 1.5L 96MY KOR	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. UNLEAD 1.5L 97-98MY KOR	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. UNLEAD 1.6-2.0L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		04. UNLEAD 1.6-2.0L IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		05. LEAD 1.6-2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		06. UNLEAD 96MY OBD-11	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		07. UNLEAD 97MY OBD-11	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		08. UNLEAD 98MY OBD-11	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		09. UNLEAD 99-00MY OBD-11	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	03. AUTOMATIC TRANSAXLE	01. -99MY(A4BF1)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. 2000MY(A4BF2)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED
	05. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM		
	08. ELANTRA 1992-1995	01. ENGINE L4-SOHC		1	READ/CLEAR DTC	2	DATA STREAM	3
02. ENGINE L4-DOHC			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
03. AUTOMATIC TRANSAXLE SYSTEM			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
04. ANTI-LOCK BRAKE SYSTEM			1	READ/CLEAR DTC	2	DATA STREAM		
05. AIRBAG SYSTEM			1	READ/CLEAR DTC	2	DATA STREAM		
09. HD COUPE 2002-2004	01. ENGINE	01. LOAD 1.6L ALL	1	READ/CLEAR DTC	2	DATA STREAM		
		02. UNLEAD 1.6L GEN	1	READ/CLEAR DTC	2	DATA STREAM		
		03. UNLEAD 1.6L EOBD	1	READ/CLEAR DTC	2	DATA STREAM		
		04. LEAD 2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		05. UNLEAD 2.0L(-CVVT) GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		06. UNLEAD 2.0L(+CVVT) GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		07. UNLEAD 2.0L(-CVVT) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		08. UNLEAD 2.0L(+CVVT) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		09. UNLEAD 2.0L(-CVVT) OBD-11	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		10. UNLEAD 2.0L(CVVT) OBD-11	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		11. LEAD 2.7L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		12. UNLEAD 2.7L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		13. UNLEAD 2.7L(T1) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		14. UNLEAD 2.7L(ZR) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		15. UNLEAD 2.7L(T1) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		16. UNLEAD 2.7L(ZR) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
03. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED		
04. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM				
09. HD COUPE 1997-2001	01. ENGINE L4-DOHC	01. UNLEAD 1.6-2.0L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. UNLEAD 1.6-2.0L IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. LEAD 1.6-2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		04. EOBD 2001MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		05. OBD-II 97MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		06. OBD-II 98MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		07. OBD-II 99-00MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	02. AUTOMATIC TRANSAXLE	01. 97-99MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. 2000MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	03. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4. AIR BLEED	
	04. SRS-AIRBAG	01. 97-99MY	1	READ/CLEAR DTC	2	DATA STREAM			
		02. 2000MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	10. SONATA 1999-2004	01. ENGINE L4-DOHC	01. UNLEAD GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. UNLEAD IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
03. LEAD ALL			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
04. UNLEAD EOBD			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
05. UNLEAD OBD-II			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
06. LPG(~2002) ALL			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
07. LPG(~2003-) ALL			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
08. UNLEAD GEN(i ndi a)			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
02. ENGINE V6-DOHC		01. UNLEAD GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		02 UNLEAD IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. LEAD ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		04. UNLEAD(TI 02S) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		05. UNLEAD(ZR 02S) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		06. UNLEAD(TI 02S) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		07. UNLEAD(ZR 02S) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		08. UNLEAD GEN(i ndi a)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	04. ANTI-LOCK BRAKE SYSTEM	01. CTC TYPE(99-02MY)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
		02. BOSCH TYPE(03MY-)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
		03. ABS (I ndi a)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
	05. SRS-AIRBAG	01. 1999-2001MY	1	READ/CLEAR DTC	2	DATA STREAM				
		02. F/LIFT	1	READ/CLEAR DTC	2	DATA STREAM				
		03. SRS (I ndi a)	1	READ/CLEAR DTC	2	DATA STREAM				
	06. TRACTION CONTROL SYSTEM	01. CTC TYPE (99-02MY)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. BOSCH TYPE(03MY-)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	10. SONATA 1994-1998	01. ENGINE L4-SOHC	01. UNLEAD 1.8L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. UNLEAD 2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			03. LEAD 1.8L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			04. LEAD 2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			05. OBD-II 97MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
06. OBD-II 98MY			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
07. SONATA SOHC			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
08. SONATA II 1.8L SOHC			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
09. SONATA II 2.0L SOHC			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
10. SONATA III 1.8L SOHC			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
11. SONATA III 2.0L SOHC			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
02. ENGINE L4-DOHC		01. UNLEAD 1.8L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. UNLEAD 2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. LEAD 2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		04. OBD-11 97MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		05. OBD-11 98MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		06. SONATA DOHC GOLD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		07. SONATA II 1.8L DOHC	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		08. SONATA II 2.0L DOHC	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		09. SONATA III 1.8L SOHC	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		10. SONATA III 2.0L DOHC	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		11. OLD SONATA	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. ENGINE V6-SOHC	01. UNLEAD 3.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. LEAD 3.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			03. OBD-11 97MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
04. OBD-11 98MY	1		READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
04. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
05. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM				
06. STS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM				
07. ELEC. POWER STEERING									
10. SONATA 1989-1993	01. ENGINE L4-SOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	02. ENGINE L4-DOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	03. ENGINE V6-SOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	04. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
11. EF SONATA ALL	01. ENGINE SYSTEM	01. EF SONATA 1.8/2.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. EF SONATA 2.4L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. EF SONATA 2.5L V6	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	02. AUTOMATIC TRANSAXLE SYSTEM	01. EF SONATA 1.8/2.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. EF SONATA 2.4L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. EF SONATA 2.5L V6	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
	03. ANTI-LOCK BRAKE SYSTEM	01. EF SONATA 1.8/2.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. EF SONATA 2.4L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. EF SONATA 2.5L V6	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

	04. AIRBAG SYSTEM	01. EF SONATA 1.8/2.0L	1 READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		02. EF SONATA 2.4L	1 READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
		03. EF SONATA 2.5L V6	1 READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION
	05. TRACTION CONTROL SYSTEM		1 READ/CLEAR DTC	2 DATA STREAM	3 ACTUATION

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

12. XG	1999-2004	01. ENGINE L4-SOHC	01. LEAD ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			02. LEAD(+ETS) ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			03. UNLEAD GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			04. UNLEAD(+ETS) GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			05. UNLEAD(TI 02S) IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			06. UNLEAD(ZR 02S) IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			07. UNLEAD(+ETS) IMM	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			08. UNLEAD(+ETS) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	02. ATUOMATIC TRANSAXLE	01. 2.0/2.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION			
		02. 3.0/3.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION			
	03. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED	5
	04. SRS-AIRBAG	01. - 2002MY	1	READ/CLEAR DTC	2	DATA STREAM	3	VERSION info			
		02. F/LIFT	1	READ/CLEAR DTC	2	DATA STREAM					
	5. TRACTION CONTROL SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION			
	13. MARCIA	1996-1998	01. ENGINE L4-DOHC	MARCIA (96-98MY)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
02. ENGINE V6-DOHC				1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
03. ATUOMATIC TRANSAXLE			MARCIA (96-98MY)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
04. ANTI-LOCK BRAKE SYSTEM			MARCIA (96-98MY)	1	READ/CLEAR DTC	2	DATA STREAM				
05. SRS-AIRBAG			MARCIA (96-98MY)	1	READ/CLEAR DTC	2	DATA STREAM				
14. CENTENNIAL	2000-2004	01. ENGINE	01. UNLEAD 3.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			02. UNLEAD 3.0L(+ETS) ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			03. UNLEAD 3.5L(+ETS) GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			04. UNLEAD 3.5L(+ETS) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			05. LEAD 3.5L(+ETS) ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			06. UNLEAD 4.5L GDI ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			07. UNLEAD 4.5L(+ETS) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			08. UNLEAD 4.5L MPI GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			09. UNLEAD 4.5L MPI EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			10. UNLEAD 4.5L MPI OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		11. LEAD 4.5L MPI ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	02. AUTOMATIC TRANSAXLE	01. 3.0/3.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. 4.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	03. ANTI-LOCK BRAKE SYSTEM	01. ITT TYPE	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED
		02. CTC TYPE(2002.09~)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED
	04. SRS-AIRBAG	01. - 2001MY(SDM-GH)	1	READ/CLEAR DTC				
		02. 2002MY-(SRE-SMART)	1	READ/CLEAR DTC	2	DATA STREAM		
	05. VDC	01. MELCO TYPE						
		02. CTC TYPE(2002.09~)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED
14. GRANDEUR 1994-1998	01. ENGINE L4-SOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	02. ENGINE L4-DOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	03. ENGINE V6-SOHD		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	04. ENGINE V6-DOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	05. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	06. ANIT-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM		
	07. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM		
15. GRANDEUR 1983-1993	01. ENGINE L4-SOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	02. ENGINE V6-SOHC		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
	03. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
16. H-100 1994-2001	01. ENGINE L4-SOHC	01. UNLEAD 94-96MY ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. UNLEAD 97-2000MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. LEAD 94-96MY ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		04. LEAD 97-2000MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		05. LEAD 97-98MY M. E	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		06. DIESEL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
17. H100-TRUCK 1997-2004	01. ENGINE L4-SOHC	01. GASOLINE	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. DIESEL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
18. H-1 1998-2004	01. ENGINE-GASOLINE 2000MY-	01. UNLEAD 2.4L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. UNLEAD 2.4L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		03. LEAD 2.4L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	02. ENGINE-GOSOLINE ~2000MY		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	03. ENGINE DIESEL	01. T/CHARGER(COVEC-F)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. T/C INTERCOOLER(COVEC)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. CRDI (A-ENG)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	04. ENGINE FBM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	05. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	06. ANTI LOCK BRAKE SYSTEM	01. 2WD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
02. 4WD		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED	
07. SRS AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM					
19. H-1 TRUCK 2001-2003	01. ENGINE DIESEL		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	02. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	03. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
	04. SRS AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM				
20. SANTAFE 2001-2004	01. ENGINE 2.0/2.4L(GASOLINE)	01. LEAD ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. UNLEAD GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. UNLEAD 2.0L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		04. UNLEAD 2.4L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		05. UNLEAD OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	02. ENGINE 2.7L(GASOLINE)	01. LEAD ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. UNLEAD GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. UNLEAD(TI 02S) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		04. UNLEAD(ZR 02S) EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		05. UNLEAD(TI 02S) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		06. UNLEAD(ZR 02S) OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	03. ENGINE(DIESEL)	01. WGT GENERAL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. WGT EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. VGT ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	04. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
	05. ANTI-LOCK BRAKE SYSTEM	01. 2WD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		02. 4WD	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION 4 AIR BLEED
	06. SRS-AIRBAG		1 READ/CLEAR DTC 2 DATA STREAM
21. TRAJET XG 2001-2004	01. ENGINE 2.0L(GASOLINE)	01. LEAD ALL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		02. UNLEAD GEN	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		03. UNLEAD EOBD	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
	02. ENGINE 2.7L(GASOLINE)	01. LEAD ALL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		02. UNLEAD GEN	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		03. UNLEAD(TI 02S) EOBD	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		04. UNLEAD(ZR 02S) EOBD	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
	03. ENGINE(DIESEL)	01. WGT	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		02. VGT	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
	04. AUTOMATIC TRANSAXLE		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
	05. ANTI-LOCK BRAKE SYSTEM		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION 4 AIR BLEED
	06. SRS-AIRBAG		1 READ/CLEAR DTC 2 DATA STREAM
22. TAXI 1994-2001	01. ENGINE L4-SOHC FBM		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
	02. AUTOMATIC TRANSAXLE		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
23. TERRACAN 2001-2004	01. ENGINE	01. 2.5L DIESEL(TCI)	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		02. 2.9L DIESEL(C/RAIL)	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		03. UNLEAD 3.5L GEN	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		04. UNLEAD 3.5L EOBD	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		05. UNLEAD 3.5L OBD-II	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
		06. LEAD 3.5L ALL	1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
	02. AUTOMATIC TRANSAXLE		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
	03. ANTI-LOCK BRAKE SYSTEM		1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION 4 AIR BLEED
	04. SRS-AIRBAG		1 READ/CLEAR DTC 2 DATA STREAM
	24. GALLOPER-II ALL	01. ENGINE V6-SOHC	01. UNLEAD 3.0L GEN
02. UNLEAD 3.0L IMM/ME			1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
03. LEAD 3.0L GEN			1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
04. LEAD 3.0L IMM			1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION
05. DIESEL(COVEC-F)			1 READ/CLEAR DTC 2 DATA STREAM 3 ACTUATION

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		02. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. ANTI-LOCK BRAKE SYSTEM	01. ~2000MY	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			02. 2001MY	BOSCH	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4
		04. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM				
25. SANTAMO	ALL	01. ENGINE L4-SOHC	01. UNLEAD 2.0L	ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. LEAD 2.0L	ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. ENGINE L4-DOHC	01. UNLEAD 2.0L	ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. LEAD 2.0L	ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. ENGINE LPG		1	READ/CLEAR DTC	2	VERSION info				
		03. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
05. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM						
26 . GALLOPER	ALL	01. ENGINE SYSTEM	01. 2.4L SOHC		1	READ/CLEAR DTC					
			02. 3.4L SOHC		1	READ/CLEAR DTC					

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

27. AVANTE	2004-2005	01. ENGINE(GASOLINE)		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED
		04. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM		
		05. TRACTION CONTROL SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
27. AVANTE	2001-2003	01. ENGINE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. AUTOMATIC TRANSAXLE		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED
		04. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM		
		05. TRACTION CONTROL SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
27. AVANTE	1996-2000	01. ENGINE L4-SOHC	01. UNLEAD 1.5L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. ENGINE L4-DOHC	01. UNLEAD 1.5L 96MY KOR	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. UNLEAD 1.5L 97-98MY KOR	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			03. UNLEAD 1.6-2.0L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			04. UNLEAD 96MY OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			05. UNLEAD 97MY OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			06. UNLEAD 98MY OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			07. UNLEAD 99-00MY OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. AUTOMATIC TRANSAXLE	01. - 99MY(A4BF1)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. 2000MY(A4BF2)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED
		05. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM		
		06. TRACTION CONTROL SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
28 . DYNASTY	ALL	01. ENGINE SYSTEM	01. DYNASTY 2.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. DYNASTY 3.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			03. DYNASTY 3.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. AUTOMATIC TRANSAXLE SYSTEM	01. DYNASTY 2.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			02. DYNASTY 3.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
			03. DYNASTY 3.5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		03. ANTI -LOCK BRAKE SYSTEM	01. DYNASTY 2. 5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. DYNASTY 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			03. DYNASTY 3. 5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		04. AIRBAG SYSTEM	01. DYNASTY 2. 5L	1	READ/CLEAR DTC	2	DATA STREAM			
			02. DYNASTY 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM			
			03. DYNASTY 3. 5L	1	READ/CLEAR DTC	2	DATA STREAM			
29 . TIBURON	ALL	01. ENGINE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. AUTOMATIC TRANSAXLE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. ANTI -LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		04. AIRBAG SYSYSTEM		1	READ/CLEAR DTC	2	DATA STREAM			
30. ATOZ	ALL	01. ENGINE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. AUTOMATIC TRANSAXLE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. ANTI -LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		04. AIRBAG SYSYSTEM		1	READ/CLEAR DTC	2	DATA STREAM			
31. GRANDEUR XG	ALL	01. ENGINE SYSTEM	01. GRANDEUR XG 2. 0/2. 5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. GRANDEUR XG 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		02. AUTOMATIC TRANSAXLE SYSTEM	01. GRANDEUR XG 2. 0/2. 5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. GRANDEUR XG 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		03. ANTI -LOCK BRAKE SYSTEM	01. GRANDEUR XG 2. 0/2. 5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. GRANDEUR XG 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		04. AIRBAG SYSTEM	01. GRANDEUR XG 2. 0/2. 5L	1	READ/CLEAR DTC	2	DATA STREAM			
			02. GRANDEUR XG 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM			
		05. ELEC. CONTROL SUSPENSION	01. GRANDEUR XG 2. 0/2. 5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. GRANDEUR XG 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
		06. TRACTION AIR/CON SYSTEM	01. GRANDEUR XG 2. 0/2. 5L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. GRANDEUR XG 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
32. EQUUS	ALL	01. ENGINE SYSTEM	01. EQUUS 3. 0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			02. EQUUS 3. 0L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	
			03. EQUUS 3. 5L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

		04. EQUUS 4.5L GDI	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
02. AUTOMATIC TRANSAXLE SYSTEM		01. EQUUS 3.0L	1	READ/CLEAR DTC	2	DATA STREAM		
		02. EQUUS 3.0L+ECS	1	READ/CLEAR DTC	2	DATA STREAM		
		03. EQUUS 3.5L+ECS	1	READ/CLEAR DTC	2	DATA STREAM		
		04. EQUUS 4.5L GDI	1	READ/CLEAR DTC	2	DATA STREAM		
03. ANTI-LOCK BRAKE SYSTEM		01. EQUUS 3.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. EQUUS 3.0L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. EQUUS 3.5L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		04. EQUUS 4.5L GDI						
04. AIRBAG SYSTEM		01. EQUUS 3.0L	1	READ/CLEAR DTC	2	DATA STREAM		
		02. EQUUS 3.0L+ECS	1	READ/CLEAR DTC	2	DATA STREAM		
		03. EQUUS 3.5L+ECS	1	READ/CLEAR DTC	2	DATA STREAM		
		04. EQUUS 4.5L GDI	1	READ/CLEAR DTC	2	DATA STREAM		
05. ELEC. CONTROL SUSPENSION		01. EQUUS 3.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. EQUUS 3.0L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. EQUUS 3.5L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		04. EQUUS 4.5L GDI	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
06. TRACTION CONTROL SYSTEM		01. EQUUS 3.0L	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		02. EQUUS 3.0L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		03. EQUUS 3.5L+ECS	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
		04. EQUUS 4.5L GDI	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION
07. VDC			1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION 4 AIR BLEED

HYUNDAI DIAGNOSTIC FUNCTION LIST V22.00 (UPDATE 06-8-9)

33. TUSCON	2004-2005	01. ENGINE(GASOLINE)	01. LEAD 2.0L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			02. UNLEAD 2.0L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			03. UNLEAD 2.0L OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			04. LEAD 2.0L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			05. UNLEAD 2.7L GEN	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			06. UNLEAD 2.7L EOBD	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			07. UNLEAD 2.7L OBD-II	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
			08. UNLEAD 2.7L ALL	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		02. ENGINE(DIESEL)		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		03. AUTOMATIC TRANSAXLE	01. 2.0/2.7L (MELCO TCM)	1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION		
		04. ANTI-LOCK BRAKE SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION	4	AIR BLEED
		05. SRS-AIRBAG	01. GENERAL	1	READ/CLEAR DTC	2	DATA STREAM				
			02. NATIONAL AVIGATION AND SPACEFLIGHT STANDARD [AMERICA]	1	READ/CLEAR DTC	2	DATA STREAM				
		06. 4WD		1	READ/CLEAR DTC						
07. FULL AUTO AIR/CON. SYSTEM		1	READ/CLEAR DTC	2	DATA STREAM	3	ACTUATION				
33. VERNA		01. SRS-AIRBAG		1	READ/CLEAR DTC	2	DATA STREAM	3	VERSION info		